

T30 v57+sss39的使用 Installation manual  
for T30 version V57+SSS39

进入DISv57方法 how to enter DIS V57?

1插入t30硬盘到t30电脑 put T30 hard disk to  
IBM T30 laptop.

2开机一直等待【一定不要按任何】大概1-2分  
钟 Start the computer and waiting(do not  
press any button, just wait) wait 1-2 mins



```
Mark
F1.*BMW DIS V57
F2. BMW SSS V39


ESC stops 10sec timer
ENTER boots default
F-keys boot OS
[98765432_ ]

ESC stops 10sec timer
ENTER boots default
F-keys boot OS
[98765432_ ]

SCO OpenServer(TM) Release 5

bootsmb: Init smb interface @ UniSoft GmbH 2002
86=(AH) SMBus Installation check: error
Boot
:
hd(40)unix smb.enabled=1 swap=hd(40) dump=hd(41)

Sizing memory
.....
.....
.....
.....
.....
```



直到出现这个界面----软件启动完成【开始诊断车】 Until you see this screen-that means software star completely(begin diagnose car)

SSS39编程软件的开启 SSS V39 coding software start

1. 开机启动软件 1. Star computer and open software

第一个画面

First screen



开机第二个画面时按下电脑的**F2**【大概**2秒**】  
When you see the second screen, press **F2**  
button on the laptop(about 2 seconds)



这样的画面就进入了sss39 Then the computer will go to SSS39.



这就是sss39的版本 This is SSS V39 Version

Operating status	Sessions current/max.	Version Progman	SSS name	IP address
usable	0 / 5	39.0.0	SSS V39	192.168.68.50

这是sss39的语言 This is SSS39 language

deutsch	english(uk)	français	italiano	español	nederlands
svenska	japanese 日本語	english(usa)	thai ไทย	taiwanese 台語	chinese 汉语
korean 한국어	bahasa indonesia	russian русский	greek Ελληνικά	turkish türkçe	português

www.eobdii.com

www.eobdii.com